

MAVAM ESPRESSO, LLC

TECHNICAL DOCUMENT

4015 Steam wand Tension

To adjust the steam wand tension on both the UCEM and Mach Two Espresso Machines you will need just a 2.5mm Allen / Hex key. Turn clockwise to tighten, anti clockwise to loosen to your desired tension. The top adjustment screw should give you plenty of adjustment for any reasonable amount of tension you require.

If you find it to be too tight or becomes very loose quickly, there are two additional 2.5mm screws on the underside of the interface on the UCEM or inside the group mounting top on the Mach Two. These can be adjusted tighter or looser depending, to give you an appropriate range of tension from just the top screw.

