

# MAVAM ESPRESSO, LLC

## TECHNICAL DOCUMENT

### How to Adjust the Cupping Gun

Tools needed: 3mm hex key

1. To fine tune your water flow from the Cupping gun, you must begin by removing the cover panel to access the protected needle valve adjustment knob.
2. Follow the diagram on the front of the knob to increase or decrease the amount of water flow, to reach the desired amount.

If you are looking to do something other than cupping and the flow is still too strong, the next step would be the water flow coming into the machine through the pressure regulator. Each Cupping Gun ships with a standard 30psi pressure regulator. We do also offer a special regulator to accommodate this need, 15psi.

Please contact [parts@mavamespresso.com](mailto:parts@mavamespresso.com) to purchase.

